



The TeraPack disk numbering scheme

Disk #	Port # MaxPac 8230	Port # MaxPac 9200/9210
0	4	0
1	5	1
2	6	2
3	7	3
4	8	4
5	9	5
6	10	6
7	11	7

Relationship between disk and port numbers
(In the case of the MaxPac 8230, ports 0 through 3 are used for the internal 4-drive RAID array)